

There is a directory on this CD-Rom labeled “BLOKDWGS.” Within this directory are standard Conley FRP Fitting drawings in AutoCAD Release 14 Format for your use. You may insert these blocks into your drawings.

The part numbering is as follows:

Example: `100-xxx-1_1-2side.dwg`

Where: 100 = the fitting number

xxx = material code

1_1-2 = fitting size in inches; i.e. 1½”

side = the drawing view; front, side, back, end, top, and bottom

Block drawings included are:

Pipe, 1.2” through 30”

#100 Cement 90 Ell, ½” through 30”

#101 Flanged 90 Ell, ½” through 20”

#102 Cement 45 Ell, ½” through 20”

#103 Flanged 45° Ell, ½” through 20”

#104 Cement Tee, ½” through 30”

#105 Flanged Tee, ½” through 30”

#106 Flange, ½” through 30”

#112 Cement Cross, ½” through 30”

#113 Flanged Cross, ½” through 30”

#114 Cement Saddle, 2” through 30”

#114F Flanged Saddle, 2” through 30”

#119 Cement Lateral, 1” through 30”

#120 Flanged Lateral, 1” through 30”

#122 Cement Coupling, ½” through 30”